

P/N 506033-07 REV. NC 06/2008

REPLACEMENT FASTFIRE™ IGNITER KIT CAT. NO. H7053

INSTALLATION INSTRUCTIONS FOR FASTFIRE IGNITERS FOR USE WITH MODEL MONTAGE™ 32FS PELLET STOVE

ELITE SERIES

KIT CONTENTS

1 ea. Igniter Assembly 1 ea. Instruction Sheet



TOOLS REQUIRED

5/32" Allen Wrench

GENERAL INFORMATION

If you encounter any problems, need clarification of these instructions or are not qualified to properly install this kit, contact you local distributor or dealer.


Read this instruction sheet in its entirety before beginning the installation.

ALL WARNINGS AND PRECAUTIONS IN THE INSTALLATION AND OP-ERATION MANUAL PROVIDED WITH THE APPLIANCE APPLY TO THESE INSTRUCTIONS.


TURN OFF THE STOVE AND ALLOW IT TO COMPLETELY COOL BEFORE PROCEEDING.


INSTALLATION INSTRUCTIONS

- Step 1. UNPLUG STOVE.
- Step 2. Open left side door and locate igniter wires and unplug them.
- **Step 3.** Open front door and remove UltraGrate[™] and ash pan.
- Step 4. Using a 5/32" allen wrench, loosen the screw inside of UltraGrate cradle on firebox back that holds igniter in place (see *Figure 1*). It does not need to be completely removed.



- Step 5. Open ash slide plate about 1-3/4" to increase the opening inside the firebox underneath the UltraGrate™. See *Figure 2*.
- **Step 6.** Rotate igniter assembly clockwise until mounting flange clears screw head.
- **Step 7.** Remove igniter assembly through the opening in the bottom of the firebox and out the ash pan opening.
- **Step 8.** Install the replacement igniter by reversing steps 4 through 7. Connect the wires as shown in *Figure 3*.





NOTE: DIAGRAMS & ILLUSTRATIONS ARE NOT TO SCALE.

Lennox Hearth Products reserves the right to make changes at any time, without notice, in design, materials, specifications, prices and the discontinuance of colors, styles and products. Consult your local distributor for fireplace code information.

